4 GAL twin tank air compressor
START UP GUIDE

If Compressor does not start:
a. Turn Switch OFF.
b. Press Reset Button.
c. Turn Switch ON.



1



Turn Switch OFF to release any remaining pressure.

2



Close
DRAIN VALVE
at bottom of lower tank.

3



Fill COMPRESSOR PUMP to center of sight glass with AIR COMPRESSOR OIL.

4



Connect AIR LINE to Coupler.

5



Plug cord into grounded 120 volt outlet and turn POWER SWITCH on.

CENTRALPNEUMATIC®

ITEM 60567

Typical Air Line Setup



Thread seal tape is recommended for all threaded connections.

Recommended Accessories

- Air Hose
- $^{1}/_{4}$″ Accessory Kit

Use of an extension cord is not recommended.

4 GAL compresor de aire con tanques gemelos

GUÍA DE ARRANQUE

Si el Compresor no arranca:
a. Coloque el interruptor OFF.
b. Botón de reinicio de prensa.
c. Coloque el interruptor ON.





1



Coloque el interruptor OFF para liberar la presión restante.

2



Cierre la VÁLVULA DE DRENAJE en la parte inferior del tanque.

3

Llene la BOMBA DEL COMPRESOR con ACEITE PARA COMPRESOR DE AIRE hasta el centro de la mirilla de cristal.

4



Conecte LA LÍNEA DE AIRE al Acoplador.

5



Conecte el cable en un tomacorriente con descarga a tierra de 120 voltios y encienda el INTERRUPTOR.

CENTRALPNEUMATIC®

Conexión típica de la línea de aire



Se recomienda usar cinta selladora para las roscas en todas las conexiones.

Accesorios Recomendados

- Manguera de Aire
- Kit de Accesorios de $^{1}/_{4}$″

No se recomienda usar extensiones de cable.